


Sensor Adjustment Guide


AEF-300/300T SERIES

SENSOR FAUCET SYSTEMS


HYBRIDFLO[®] FIXEDFLO[®] HEALTHFLO[®]




AEF-300




AEF-301




AEF-302




AEF-303




AEF-304




AEF-306




AEF-307




AEF-320




AEF-321




AEF-322




AEF-323



AEF-300T



AEF-302T



AEF-304T



AEF-305T




Advanced Modern Technologies Corporation

19800 Nordhoff Place, Chatsworth, CA 91311


Tel: (818) 883-2682 Toll Free: (800) 874-7822 Fax: (818) 883-2620

www.amtccorporation.com


Identify Your Faucet System




Identify Your Operating System




- Green Reset Button = 300 Series
- Red Reset Button = 300T Series



- Black Motor Cover = HYBRIDFLO®




- Green Motor Cover = FIXEDFLO®



- Blue Motor Cover = HEALTHFLO®

Identify Your Faucet Model



Sensor Distance Adjustment

This section is for 300 Series spouts only.

(Models AEF-300, AEF-301, AEF-302, AEF-303, AEF-304, AEF-306, AEF-307, AEF-320, AEF-321, AEF-322, AEF-323)

1. Push and hold reset button on control box (pictured in Figure 17). Water will turn ON for approximately 5 seconds and then OFF. Release reset button. The sensor is now in setup mode.
2. Position the palm of your hand vertically and hold it at desired sensing distance. You will see a quick flashing red light in sensor window.
3. Hold your hand at the desired sensor distance for approximately 15 seconds while red light is flashing until solid red light comes on. Faucet will turn ON and then OFF by itself once when sensor range is set.




Figure 17

This section is for **300T Series** spouts only.

(Models AEF-300T, AEF-302T, AEF-304T, AEF-305T)

1. Locate the reset button on the control box as pictured in Figure 18.
2. Push and hold reset button on control box (pictured in Figure 18). Water will turn ON for approx. 5-6 seconds then turn OFF. Release reset button. Sensor will now self-adjust (process takes 15-20 seconds). Water will turn ON and OFF by itself one time after the sensor has self-adjusted.




Figure 18

Warranty

AMTC WARRANTS ITS PRODUCTS TO BE FREE OF DEFECTS IN MATERIAL AND WORKMANSHIP FOR A PERIOD OF FIVE (5) YEARS FROM DATE OF PURCHASE, WHEN PROPERLY INSTALLED AND UNDER NORMAL USE AND SERVICE. THESE PROVISIONS DO NOT INCLUDE THE BATTERIES SHIPPED WITH THE PRODUCTS. A DEFECTIVE PRODUCT MAY BE RETURNED TO AMTC OR ITS AUTHORIZED REPRESENTATIVES WITHIN FIVE (5) YEARS FROM DATE OF PURCHASE WITH THE PROPER INVOICE OF PURCHASE. AMTC, AT ITS DISCRETION, WILL REPLACE OR REPAIR DEFECTIVE PRODUCT AT NO CHARGE. CLAIMS FOR LABOR, TRANSPORTATION, AND ANY OTHER INCIDENTAL COSTS WILL NOT BE ALLOWED. AMTC WILL NOT BE RESPONSIBLE FOR ANY CONSIDERABLE DAMAGES OF ANY KIND WHATSOEVER.

FOR TECHNICAL SUPPORT PLEASE CALL TOLL FREE 1-800-874-7822 OR VISIT OUR WEBSITE AT WWW.AMTCORPORATION.COM

MAKE SURE TO VISIT OUR WEBSITE PERIODICALLY FOR INFORMATION ON NEW PRODUCTS AND TO DOWNLOAD ANY IMPORTANT PRODUCT DOCUMENTS THAT YOU MAY NEED IN THE FUTURE.



Advanced Modern Technologies Corporation

19800 Nordhoff Place, Chatsworth, CA 91311

Tel: (818) 883-2682 Toll Free: (800) 874-7822 Fax: (818) 883-2620

www.amtcorporation.com